

FIG. 1







FIG. 2










FIG. 6




FIG. 7





FIG. 8









FIG. 9





12/21

<u>160</u>






FIG. 13




FIG. 14

WO 2005/022292




FIG. 15




FIG. 16






FIG. 17

18/21





WO 2005/022292




FIG. 20

WO 2005/022292

79, 104

- 1 | TRACKER TAG ID=123456789:
- 2 | # CHANGE IN STATE CONDITION;
- 3 | CISC POSITION:
- 4 | CISC TIME;
- 5 | CISC VIBRATION::TRANSITION ENGINE OFF TO RUNNING;
- 6 | CISC VIBRATION::TRANSITION ENGINE RUNNING TO OFF AND REMAINING
- 7 | OFF 10 MINUTES;
- 8 CISC TEMPERATURE:: RISING TRANSITION TO > 40 F;
- 9 | CISC TEMPERATURE:: FALLING TRANSITION TO < 40 F AND REMAINING < 40
- 10 | F 5 MINUTES;
- 11 | CISC SELF-TEST-PASS:: YES;
- 12 | CISC SELF-TEST-FAIL:: YES:
- 13 | CISC PAGE;
- 14 # DATA ACQUSITION CONDITION;
- 15 DAC POSITION:: ON VIBRATION CHANGE IN STATE, PERIODIC 10 MINUTES
- 16 WHILE ENGINE RUNNING:
- 17 DAC TIME:: ON VIBRATION CHANGE IN STATE, PERIODIC 10 MINUTES
- 18 | WHILE ENGINE RUNNING:
- 19 | DAC VIBRATION:: ON VIBRATION CHANGE IN STATE, ALSO ACQUIRE
- 20 | POSITION, ALSO ACQUIRE TIME:
- 21 | DAC TEMPERATURE:: ON TEMPERATURE CHANGE IN STATE, PERIODIC 5
- 22 | MINUTES WHILE > 40 F, ALSO ACQUIRE POSITION, ALSO ACQUIRE TIME;
- 23 | DAC SELF-TEST-PASS:: ON SELF-TEST-PASS CHANGE IN STATE, ALSO
- 24 | ACQUIRE POSITION, ALSO ACQUIRE TIME;
- 25 | DAC SELF-TEST-FAIL:: ON SELF-TEST-FAIL CHANGE IN STATE, ALSO
- 26 | ACQUIRE POSITION, ALSO ACQUIRE TIME;
- 27 DAC PAGE:
- 28 | # DATA DOWNLOAD CONDITION;
- 29 DDC POSITION:
- 30 DDC TIME:
- 31 | DDC VIBRATION:: ON VIBRATION CHANGE IN STATE, PERIODIC 8 HOURS
- 32 WHILE ENGINE RUNNING, ALSO DOWNLOAD ALL:
- 33 | DDC TEMPERATURE:: ON TEMPERATURE CHANGE IN STATE, PERIODIC 5
- 34 | MINUTES WHILE > 40 F, ALSO DOWNLOAD POSITION AND TIME;
- 35 | DDC SELF-TEST-PASS;
- 36 | DDC SELF-TEST-FAIL:: ON SELF-TEST-FAIL CHANGE IN STATE, ALSO
- 37 | DOWNLOAD POSITION AND TIME;
- 38 | DDC PAGE:: USER 123 FOR ALL DATA DOWNLOAD CONDITIONS;
- 39 DDC PAGE:: USER 456 FOR SELF-TEST-FAIL DATA DOWNLOAD CONDITION;